




IN-ROOM EQUIPMENT USER GUIDE

Model: EMSB25XC




PRODUCT DESCRIPTION

General overview



Control Panel




Symbol	Function	Description
1 —	Display	Shows the settings and current time.
2    	Function pads	To set the microwave / grill / convection / combi / auto defrost and auto cooking function. To set the microwave / combi / grill / auto defrost and auto cooking function.

Symbol	Function	Description
3 +10 sec , min	Time Set pads	To set the desired time.
4 	Start / +30 sec	To start the appliance or increase the cooking time for 30 seconds at full power.
5 	Setting pads	To set the time, weight or temperature.
6 	Stop / Clear	To deactivate the appliance or delete the cooking settings.
7 	Favourite	To save one favourite combination of cooking parameters.
8 	Clock	To set the clock / reminder.

Accessories


Turntable set

 Always use the turntable set to prepare food in the microwave.



Glass cooking tray and roller guide.

Grill Rack



Use for:

- grilling food
- combi cooking
- convection cooking

BEFORE FIRST USE

 **WARNING!**
Refer to Safety chapters.

Initial Cleaning

 **CAUTION!**
Refer to chapter "Care and Cleaning".

- Remove all the parts and additional packaging from the microwave.
- Clean the appliance before first use.

Setting the time

When you connect the appliance to the electrical supply or after a power cut, the display shows 0:00 and an acoustic signal sounds.



hour clock system.

1. Press  twice.
2. Press the Setting pads to set the hours.
3. Press  to confirm.
4. Press the Setting pads to set the minutes.

DAILY USE



WARNING!

Refer to Safety chapters.

General information about using the appliance

- After you deactivate the appliance, let the food stand for some minutes.
- Remove the aluminium foil packaging, metal containers, etc. before you prepare the food.

Cooking

- If possible, cook food covered with material suitable for use in the microwave. Only cook food without a cover if you want to keep it crusty
- Do not overcook the dishes by setting the power and time too high. The food can dry out, burn or catch fire in some places.
- Do not use the appliance to cook eggs or snails in their shells, because they can explode. With fried eggs, pierce the yolks first.
- Prick food with "skin" or "peel", such as potatoes, tomatoes, sausages, with a fork several times before cooking so that the food does not explode.
- For chilled or frozen food, set a longer cooking time.
- Dishes which contain sauce must be stirred from time to time.
- Vegetables that have a firm structure, such as carrots, peas or cauliflower, must be cooked in water.
- Turn larger pieces after half of the cooking time.
- If possible, cut vegetables into similar-sized pieces.
- Use flat, wide dishes.

The display shows ON and the clock is shown on the display when the microwave is in standby mode.

If you do not want the clock to be shown when the microwave is in standby mode press $\oplus$ or $\ominus$ and set OFF. Press  to confirm.

- Do not use cookware made of porcelain, ceramic or earthenware with small holes, e. g. on handles or unglazed bottoms. Moisture going into the holes can cause the cookware to crack when it is heated.
- The glass cooking tray is a work space for heating food or liquids. It is necessary for the operation of the microwave.

Defrosting meat, poultry, fish

- Put the frozen, unwrapped food on a small upturned plate with a container below it so that the defrosting liquid collects in the container.
- Turn the food after half of the defrosting time. If possible, divide and then remove the pieces that started to defrost.

Defrosting butter, portions of gâteau, quark

- Do not fully defrost the food in the appliance, but let it defrost at room temperature. This gives a more even result. Fully remove all metal or aluminium packaging before defrosting.

Defrosting fruit, vegetables

- Do not fully defrost fruit and vegetables, which are to be further prepared while raw, in the appliance. Let them defrost at room temperature.
- You can use a higher microwave power to cook fruit and vegetables without defrosting them first.

Ready meals

- You can prepare ready meals in the appliance only if their packaging is suitable for microwave use.
- You must follow the manufacturer's instructions printed on the packaging

(e.g. remove the metal cover and pierce the plastic film).

Suitable cookware and materials

Cookware / Material	Microwave			Grilling / Convec-tion
	Defrosting	Heating	Cooking	
Ovenproof glass and porcelain (with no metal components, e. g. Pyrex, heat-proof glass)	X	X	X	X
Non-ovenproof glass and porcelain ¹⁾	X	--	--	--
Glass and glass ceramic made of ovenproof/frost-proof material (e. g. Arcoflam), grill shelf	X	X	X	X
Ceramic ²⁾ , earthenware ²⁾	X	X	X	--
Heat-resistant plastic up to 200 °C ³⁾	X	X	X	--
Cardboard, paper	X	--	--	--
Clingfilm	X	--	--	--
Roasting film with microwave safe closure ³⁾	X	X	X	--
Roasting dishes made of metal, e. g. enamel, cast iron	--	--	--	X
Baking tins, black lacquer or silicon-coated ³⁾	--	--	--	X
Baking tray	--	--	--	X
Browning cookware, e. g. Crisp pan or Crunch plate	--	X	X	--
Ready meals in packaging ³⁾	X	X	X	X

- ¹⁾ With no silver, gold, platinum or metal plating / decorations
²⁾ Without quartz or metal components, or glazes which contain metals
³⁾ You must follow the manufacturer's instructions about the maximum temperatures.

X suitable **-- not suitable**

Power setting table

Press 	Power setting	Approximate Percentage of Power
1 time	900 Watt	100 %
2 times	700 Watt	77 %

Press 	Power setting	Approximate Percentage of Power
3 times	500 Watt	55 %
4 times	300 Watt	33 %
5 times	100 Watt	17 %

Other functions

Press 	Display	Function mode
Grilling		
1 time		Full Grill
Combi Cooking		
2 times		Microwaves, Convection
3 times		Microwaves, Grill
4 times		Convection, Grill,
5 times		Microwaves, Convection, Grill
Convection Cooking		
6 times		Convection cooking at set temperature

Quick Start



The maximum cooking time is 95 minutes.

Press  to activate the microwave for 30 seconds at full power. The cooking time increases by 30 seconds with each additional press of the button.

Defrosting

You can choose between 2 defrosting modes:

- Weight defrosting

- Time defrosting



Do not use weight defrosting on food that is left out of the freezer for more than 20 minutes, or for frozen ready-made food.



To activate weight defrosting you must use more than 100 g of food and less than 2000 g.



To defrost less than 200g of food place it on the edge of the turntable.

1. Repeatedly press to set the weight or time defrosting.
2. Press the Setting pads to set the time or weight.
For weight defrosting the time is set automatically.
3. Press to confirm and activate the microwave.

Convection Cooking

For better result preheat the microwave to the right temperature before inserting the food.



You can use the Kitchen Timer as a time reminder for this function.

1. Repeatedly press to set the Convection Cooking.
2. Press the Setting pads to set the temperature.
3. Press to confirm and activate the microwave.

Grilling and Combi Cooking

1. Repeatedly press to set the Grilling or Combi Cooking function.
2. Press the Setting pads to set the time.
3. Press to confirm and activate the microwave.



An acoustic signal sounds after half of the cooking time passes. You can turn over the food.

AUTOMATIC PROGRAMMES



WARNING!
Refer to Safety chapters.

Auto cooking

Use this function to easily cook favourite food. The microwave automatically sets the optimum settings.

1. Repeatedly press to set the desired menu.
2. Press the Setting pads to set the weight.
3. To change the set menu for a different one press .
4. Press to confirm and activate the microwave.

Display	Menu	Weight
	Auto Reheat	150 g 250 g 350 g 450 g 600 g
	Beverage	1 cup
	Pizza	200 g 300 g 400 g

Display	Menu	Weight
	Popcorn	50 g 100 g
	Chicken	500 g 750 g 1000 g 1200 g
	Meat	150 g 300 g 450 g 600 g
	Potato	230 g 460 g 690 g
	Vegetable	150 g 350 g 500 g
	Fish	150 g 250 g 350 g 450 g 650 g
	Pasta	50 g (add 450 ml of water) 100 g (add 800 ml of water) 150 g (add 1200 ml of water)

Favourite

You can save only one Favourite setting.

Use this function to save a setting that you often use with the microwave.

1. Set the function and parameters you want to save.
Refer to the procedure for the function you want to set.

2. Press ☆ and hold for 2 seconds. An acoustic signal sounds after the settings are saved.

Using the Favourite programme

1. Press ☆.
2. Press  to activate the microwave.

USING THE ACCESSORIES



WARNING!

Refer to Safety chapters.

Inserting the turntable set




CAUTION!

Do not cook food without the turntable set. Use only the turntable set provided with the microwave.




Never cook food directly on the glass cooking tray.

- 1. Place the roller guide around the turntable shaft.
- 2. Place the glass cooking tray on the roller guide



Inserting the grill rack

Place the grill rack on the turntable set.



ADDITIONAL FUNCTIONS

Child Safety Lock

The Child Safety Lock prevents an accidental operation of the microwave.

Press and hold for 3 second.
An acoustic signal sounds.
When the Child Safety Lock is active the display shows .

Kitchen Timer

You can set a maximum 95 minutes.

- 1. Press .
- 2. Press the Setting pads to set the time.

The Kitchen Timer activates automatically after a few seconds.
When the set time is reached, an acoustic signal sounds.

- 3. Press to cancel the function.



When the Timer is active the display shows the active function. To see how much time is left press .



The Timer still works when you open the door or pause the microwave.

HINTS AND TIPS



WARNING!
Refer to Safety chapters.

Tips for the microwave

Problem	Remedy
You cannot find details for the amount of food prepared.	Look for a similar food. Increase or shorten the length of the cooking times according to the following rule: Double the amount = almost double the time , Half the amount = half the time



frasershospitality.com