IN-ROOM EQUIPMENT USER GUIDE

DEVICE LAYOUT

DEVICE LAYOUT

① 3.5 MM INPUT

Plug in an analogue audio device with a 3.5 mm stereo jack.

② SOURCE SELECTION

Push the source button to toggle between Bluetooth® and AUX audio sources. A lit indicator shows which source is selected. This can also be selected from the Marshall Bluetooth app.

Caution: Make sure that the volume is set to low on both the speaker and the audio device before using the speaker

③ AUDIO CONTROLS

Acton III includes three controls for adjusting the audio.

I. Volume control
II. Bass control
III. Treble control

④ MEDIA CONTROL

Control the audio directly from the top panel when playing via Bluetooth.

I. Push to play or pause
II. Push right to skip forward
III. Push left to skip back
IV. Hold left or right to rewind or fast forward

Playback can also be controlled from the Marshall Bluetooth app.

⑤ POWER SWITCH

Use the power switch to turn the speaker on or off.

DEVICE LAYOUT

6 POWER INPUT

Use the included mains lead to connect Acton III to the wall socket.

INSTRUCTIONS ENGLISH

GETTING STARTED

I. Connect the mains lead to the mains input on your speaker, then connect the mains plug to the wall socket.
II. Use the power switch to turn the speaker on.
III. Download the Marshall Bluetooth app and follow the in-app instructions to set up your speaker

Important: Always ensure that the mains lead, plug and speaker are compatible with your mains supply and wall socket.

Caution: Always unplug the mains lead from the wall socket before disconnecting it from the speaker.

BLUETOOTH PAIRING

I. Use the source button to select Bluetooth.
II. Push and hold the source button until the Bluetooth LED pulses red.
III. Select ACTON III from your audio device's Bluetooth list.

Acton III can be connected to two Bluetooth devices at the same time. If a connected device is playing, a second connected device cannot start playing until the first device is paused.

CONNECTING AN AUX DEVICE

I. Connect a 3.5 mm stereo jack to the AUX input on the top of the speaker.
II. Connect the other end of the lead to the audio output on your audio source.

III. Use the source button to select AUX.

Note: Audio leads are not included.

NETWORK STANDBY MODE

Acton III will go into network standby if left unused for 10 minutes to save energy. Any connected Bluetooth device will be disconnected.

Interact with any control or button on the top panel, reconnect a Bluetooth device or play anything via the physical inputs to wake up the speaker.

PERFORMING A FACTORY RESET

A factory reset will return the speaker to its original settings, excluding any firmware updates.

Note: This will delete all user settings and the speaker needs to be set up again.

I. Push and hold the media control for more than 10 seconds and the speaker will reset.
II. Remove ACTON III from your audio device's Bluetooth list before pairing again.

MARSHALL BLUETOOTH APP

Download the Marshall Bluetooth app to get the most out of your speaker and keep it up to date with the latest software.

FRASER SUITES
SUKHUMVIT - BANGKOK

frasershospitality.com